



N.	QUANTITY and DESCRIPTION	N.	QUANTITY and DESCRIPTION	N.	QUANTITY and DESCRIPTION
200	2 BUTT PLATE SCREW	230	1 WOOD FORE-END	262	1 SINGLE TRIGGER SELECTIVE SAFETY
201	1 BUTT PLATE	231	1 COCKING PIECE	263	1 ROCKER ARM
202	1 STOCK	232	2 FORE-END SCREW	264	1 ROCKER ARM SPRING
203	1 TOP LEVER OR LOCKING LEVER	233	2 HINGE PIN	265	1-2 ROCKER ARM PIN
204	1 SAFETY (DOUBLE TRIGGER)	234	3 FIRING PIN/LOCKING LEVER PIN	266	1 SINGLE TRIGGER
205	1 SEAR LEVER PIN	235	1 SPRING PIN FOR TRIGGER PLATE	267	1 SINGLE TRIGGER RETURN SPRING
206	1 TRIGGER PLATE SCREW	236	1 LOCKING BOLT	268	2 SEAR LEVER RETURN SPRING, SINGLE TRIGGER
207	1 SAFETY SPRING	237	2 STRIKER SPRING	269	2 SEAR LEVER, SINGLE TRIGGER
208	1 SAFETY SPRING SCREW	238	1 FIRING PIN, LEFT	270	1 AUTOMATIC SAFETY ROD
209	1 LOCKING LEVER SPRING STAKE	239	1 FIRING PIN, RIGHT	271	1 STATIONARY SAFETY FOR NON-SELECTIVE TRIGGER
210	1 LOCKING LEVER PAWL SPRING	240	2 DOUBLE TRIGGER GUIDE PIN	272	1 ADJUSTABLE SINGLE TRIGGER UPPER PART
211	1 LOCKING LEVER PAWL	241	1 HAMMER, LEFT	273	1 ADJUSTABLE SINGLE TRIGGER LOWER PART
212	1 LOCKING LEVER PIN	242	1 HAMMER, RIGHT	274	1 ADJUSTABLE SINGLE TRIGGER RETAINING SCREW
213	1 ACTION BODY	243	2 SEAR LEVER (DOUBLE TRIGGER)	275	1 FORE-END IRON SNAP LEVER WITH RELEASE BUTTON
214	2 HINGE PIN SCREW	244	2 SEAR LEVER SPRING (DOUBLE TRIGGER)	276	1 RELEASE BUTTON FOR SNAP LEVER
215	1 EXTRACTOR SCREW	245	1 LOCKING LEVER SPRING	277	2 PLATE-HOLDING SCREW
216	1 NORMAL EXTRACTOR	246	1 LOCKING LEVER RETURN CYLINDER	278	1 SIDE-PLATES, LEFT
217 N	1 BARREL EXTRACTOR	247	1 LOCKING LEVER RETURN CYLINDER SCREW	279	1 SIDE-PLATES, RIGHT
217 E	1 BARREL EJECTOR	248	2 MAINSPRING	280	1 SIDE PLATE-JUNCTION THROUGH SCREW
218	1 TOP RIB	249	1 STOCK SLING SWIVEL	281	2 EJECTOR RETURN SPRING
219	1 TENON	250	1 STOCK BOLT	282	2 EJECTOR RETURN SPRING GUIDE PIN
220	2 LATERAL RIB	251	1 WASHER	283	1 EJECTOR, LEFT
221	2 TUBE	252	1 DOUBLE TRIGGER, LEFT	284	1 EJECTOR, RIGHT
222	1 FRONT SIGHT	253	1 DOUBLE TRIGGER, RIGHT	285	1 EJECTOR RETAINER PLATE, LEFT
223	1 BARREL SLING SWIVEL	254	1 TRIGGER GUARD SCREW	286	1 EJECTOR COUPLING PLATE, LEFT
224	4 BARREL SLING SWIVEL SCREW	255	1 TRIGGER GUARD	287	2 EJECTOR RETAINER PLATE SPRING, LEFT
225	1 FORE-END SNAP LEVER SCREW	256	1 DOUBLE TRIGGER PIN	288	2 EJECTOR COUPLING PLATE PAWL
226	1 FORE-END SNAP LEVER	257	1 HAMMER PIN	289	1 EJECTOR RETAINER PLATE, RIGHT
227	1 FORE-END SNAP LEVER SPRING	258	1 TRIGGER PLATE	290	2 EJECTOR RETAINER PLATE SCREW
228	1 FORE-END SNAP LEVER GUIDE PIN	259	1 COCKING LEVER GUIDE PIN	291	1 EJECTOR COUPLING PLATE, RIGHT
229	1 FORE-END IRON	260	1 COCKING LEVER SPRING	292	1 EJECTOR COCKING LEVER, RIGHT
229 P	1 FORE-END IRON WITH RELEASE BUTTON	261	1 COCKING LEVER	293	1 EJECTOR COCKING LEVER, LEFT